	Humidity an For pressuriz	SALA d Temperature Probe HMP8 zed installations 040 bars February 2022		Probe type	Probe cable	Sensor type	Filter type	Sensor purge	S-485 baud rate	Data, Parity, Stop bits	Modbus address	Reserved	Installation accessory	Connection cable
	Order code		HMP		G		<u> </u>	<u>, , , , , , , , , , , , , , , , , , , </u>	<u> </u>		<u> </u>		_	
1	Probe type				F							-		
	i lobe type	HMP8 for pressurized applications 040 bars		8										
2	Cable lengt	h between probe head and probe body			1									
1	ouble lengt	2 m			G									
3	Sensor type				<u> </u>	1								
ľ		, Humicap R2 composite sensor, allows sensor pu	rae			1								
		Humicap R2 sensor, no sensor purge	90			2								
4	Filter type					-	1							
l '		Sintered stainless steel filter	spare: HM4728	0.SP			в							
		Stainless steel grid	spare: HM4745				D							
5	Sensor pure	ge, default purge interval 24h	00010.1111110	00/			-	J						
ľ	1)	Purge on, composite sensor required (selection 3)					0						
	.,	Purge off	,					1						
6	RS-485 bau							-	1					
ľ	1)	19200 bps							Α					
	.,	9600 bps							В					
7	Data, Parity									1				
-	1)	8, N, 2								0				
	.,	8, E, 1								2				
		8, O, 1								4				
8	Modbus add	• •								-	1			
Ũ	1)	240									Α			
	.,	110									В			
		120									С			
		130									D			
9	Reserved											1		
		None										0		
10	Probe mour	nting accessory												
		Ball valve installation kit	spare	: BA	LLV	۲AL	VE-	1					L	
		Installation fitting for NPT 1/2"	spare										м	
		Installation fitting for ISO 1/2"	spare					SP					Ν	
		Installation fitting set: ISO 1/2" + NPT 1/2"	spare						W2 ⁻	120	765	SP	Р	
11	Connection													
		None												0
		1.5m with open wires	spare	: 223	3263	BSP	•							1
		10m, with open wires	spare											2
	1) Fastam (m)	re-set, can be changed in the field with a service cable												_

1) Factory pre-set, can be changed in the field with a service cable (P/N 242659)

Probe can be connected to INDIGO series of transmitters regardless of the output configuration.

Selections in **bold** are included in the prices of the basic versions.

Selections in italic are available at an extra price.

Example of order code with typical settings:

For use with INDIGO transmitters	HMPX	8	G	1	В	0	Α	0	Α	0	P	0
For use with Modbus RTU	HMPX	8	G	1	В	0	Α	0	Α	0	Ρ	2